




Charger Cradle Wiring Layout




Charger Cradle Front View



From Mixer Junction Box




Amp inline Connector
206036-3




Meter Cable End
Male Pins 66099-5



Standard Pinout
Top VJ e W







AdMix Pumps




24 Volt Wiring



AdMix Pumps






12 volt Wirin





2003/04 Valve Wiring

Each solenoid connector has 2 wires which are bundled in a common cable leading to the electrical control box.




Prox Sensor

Optional Hydraulic Vibrators



Pneumatic Vibrator




+ This symbol indicates power input to the connector. Each wire is connected to the terminal next to the LED light.

— This symbol indicates the ground connection for the connector. Each wire is connected to the terminal next to the red capacitor.

The third and widest pin is not used.

Addendum 'A'

T-Handle Wiring



Vibrator Switch



Switch Notch