



Control Panels




Main Panel



With Chain Oiler






Charger Cradle Wiring




Valve Wiring


Each solenoid connector has 2 wires
Blue and white wires are ground
Brown and Black wires are Power



Prox Sensor



Vibrator



+ This symbol indicates power input to the connector.

This symbol indicates the ground connection for the connector.

The third and widest pin is not used.

Auger Belt

**Pressure
Reducing
Valve**

FLOW CONTROLS

Swing

Chute

Boom

Chute

Boom

**COUNTER
BALANCE
VALVES**

**Swing
Check
Valve**

**Water Pump Speed
Adjustment**

**Power
Swing**

